



Electric HOTBAG Catering Bag – Usage & Care Instructions

GENERAL INSTRUCTIONS

- 1.) Open the bag and insert the black stiffener panels inside the 2 side walls (shown below).



- 2.) Secure the gray side panels / slide rails against the 2 side walls. Be sure to secure the top edge of the grey panel inside the channel at the top of the bag, and push the bottom in against the wall (shown below).



- 3.) The bag comes with the heating elements pre-installed, so simply plug the bag into an available 12vDC outlet, or into an Electric HOTBAG AC Power Supply (purchased separately)
- 4.) Allow the bag to pre-heat for 45-60min

WASHING INSTRUCTIONS

- 1.) Remove Heating Elements from the front and rear panels of the bag
- 2.) Remove all of the black stiffener/support panels.
- 3.) HOTBAGS can be washed using a front loading commercial washing machine, such as those found at your local Laundromat.
- 4.) Pre-treat any heavily soiled areas with a dish detergent such as Dawn. This will help loosen existing grease and dirt, making the machine wash more effective.
- 5.) Wash bags on “Normal” cycle, using HOT water and a standard detergent.

- 6.) After bags have gone through a complete cycle, check the bags for badly soiled areas which may not have been fully cleaned with a single treatment, and wash again.

DRYING INSTRUCTIONS

- 1.) Dry bags on HIGH heat for approx. 20 minutes.
- 2.) If bags are still slightly damp, install the heating elements in the bag and plug the bag into a power supply. This will help dry the bags from the inside out, and will reduce the risk of mildew / mold.

DO NOT

- 1.) **Do Not** stand bags on end while they are in use.
- 2.) **Do Not** use dishwasher for cleaning.
- 3.) **Do Not** dry clean.
- 4.) **Do Not** place sharp objects in or on HOTBAG
- 5.) **Do Not** leave HOTBAG plugged into 12v cigarette power outlet when not in use (vehicles battery may discharge).

TROUBLE SHOOTING

- 1.) Turn cigarette plug inside the lighter socket to improve connection. The LED will illuminate on the power plug when a proper connection is made.
- 2.) Check fuse located in the cigarette plug (push down metal tip and turn counter clockwise to remove fuse)
- 3.) Check fuse of your vehicles cigarette lighter, located in the main fuse panel.
- 4.) Check power cord and plug for broken or frayed wires.
- 5.) Make sure connector contacts are clean and free of corrosion.
- 6.) If your HOTBAG does not heat up after reviewing the above steps, contact the Check Corporation at 1-800-WARMS-UP.