A. Massage Only System

The Massage system has four different settings:

Push the non-latching switch upwards once for lower back low-intensity massage, twice for a more high-intensity massage in the lower back, a third time for your upper back and lower back low-intensity massage, a fourth time for both upper and lower back at high-intensity massage and a fifth time to shut the massage function off.

II. WHAT TO EXPECT

The massage will instantly turn on once the switch is pushed to your preferred setting.

III. IF MASSAGE IS NOT FELT CHECK THE FOLLOWING:

- 1) Check the fuse. The 7.5 AMP fuse is located near the vehicle fuse box in a separate fuse holder. In some installations a fuse tap may have been installed on an accessory fuse in the fuse box in order to provide power for the seat heater. The fuse tap should have been placed on the power side of the accessory fuse. If the fuse tap was not installed on the power side the accessory fuse may have blown.
- 2) Check all the connectors to make sure they are tightly engaged.
- 3) Check the connections to 12 volts and ground. NOTE: The red wire MUST be connected to 12 volts and the black wire to ground.
- 4) For further information contact your installation dealer.

Please fill out and return the Warranty Card immediately to validate warranty.

Place Postage Here

Check Corporation
1800 Stephenson Highway
Troy, MI 48083

OWNERS MANUAL CHECK CORPORATION SEAT HEATERS

CONGRATULATIONS!

On the installation of the Check Corporation's Quality Massage System into your vehicle! ****

You will now be experiencing a new level of driving and riding comfort in your vehicle.

Your system is safe and durable and manufactured to the highest quality standards.

No additional care of your seat is required. Simply follow the Vehicle manufacturers recommendation for cleaning

For service or additional information contact your dealer.

Limited Warranty

This Product is warranted to be free from defects in manufacturing and workmanship and is guaranteed to work for three years or 36,000 miles, whichever occurs first. This Limited Warranty covers the repair or replacement of the seat heater components only, and does not cover any costs related to or damage resulting from the installation of the seat heater. Custom designed seat heaters must only be used in seat applications for which they were designed, tested and approved by Check Corporation, and failure to properly install the designated seat heater product, or improper installation or misuse of any component, will void this Limited Warranty.

MANUFACTURER'S LIMITED REPAIR REPLACEMENT WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR DUTIES OR WARRANTIES ARISING FROM A COURSE OF DEALING, USAGE OF TRADE OR COMMON LAW. IN NO EVENT SHALL MANUFACTURER BE LIABLE FOR PROXIMATE, INCIDENTAL, CONSEQUENTIAL OR OTHER DAMAGES, INCLUDING BUT NOT LIMITED TO DAMAGES FOR LOSS OF PROFITS OR PRODUCTION OR INJURY TO PERSON OR PROPERTY. THE CONSUMER OF THIS PRODUCT SHOULD CONTACT ITS INSTALLATION DEALER FOR ANY WARRANTY CLAIM AND RETURN WARRANTY CARD TO VALIDATE WARRANTY.

PHONE: 1-800-WARMS-UP (927-6787) FAX: 248-680-2326

VISIT US ON THE WEB AT: www.seatheater.com

NAME: ADDRESS: _						corporat
Phone # (_ INSTALLER			Date	Installed:		
TYPE OF VE	HICLE:					
□ Ver	y Satisfied u satisfied	□ Satisfied I with the in	ormance of your control of you	I □ Very U our massag	nsatisfic ge Syst	ed em?
□ Ver	*					